

07.07.2024

SAFETY NOTE

*Use of the FINSTERWALDER Paralock 3 paragliding carabiner
in conjunction with speed systems*

During the unlocked operation of the Paralock 3, it has happened that the risers have been released unintentionally. Loose hanging lines of the speed system wrapped around the release button in such a way that when the speed system was subsequently operated, the swivel lever was turned to the open position. The incident had no serious consequences.

If the Paralock 3 is used in conjunction with a speed system, it must be locked before take-off in addition to the normal locking mechanism, unless precautions have been taken to prevent the release button from becoming wrapped around during flight.

